



HANGER BOLTS



HANGER BOLTS														Hanger Bolt & Stud							
Diameter & Thread Pitch	C		A		B		D		Diameter & Thread Pitch	C		A		B		D					
	Standard Length	Machine Thread Length	Lag Thread Length	Center Space	Standard Length	Machine Thread Length	Lag Thread Length	Center Space		Standard Length	Machine Thread Length	Lag Thread Length	Center Space								
6-32	5/8	1/4	3/8	-	1/4-20	2	1	1	-	3/8-16	1-1/2	1/2	1	-	1/2-13	3	1-1/2	1-1/2	-		
	3/4	3/8	3/8	-		2-1/4	1	1-1/4	-		2	1	1	-		2-1/2	1	1-1/2	-		
	7/8	1/4	5/8	-		2-1/2	1	1-1/2	-		3	1-1/2	1-1/2	-		3	1-1/2	1-1/2	-		
	1	3/8	5/8	-		2-3/4	1-1/4	1-1/2	-		3-1/2	1-1/2	2	-		4	2	2	-		
8-32	5/8	1/4	3/8	-		3	1-1/2	1-1/2	-		4	2	2	-		4-1/2	1-1/8	3	3/8	5/8	-
	3/4	3/8	3/8	-		3-1/2	1-1/2	2	-		4-1/2	1-1/8	3	3/8		5	1-3/8	3	5/8	1	-
	7/8	1/4	5/8	-		4	2	2	-		5	1-3/8	3	5/8		5-1/2	1-1/2	3	1	-	
	1	3/8	5/8	-		4-1/2	1-1/8	3	3/8		6	1-1/2	3	1-1/2		6	1-1/4	3	1-3/4	-	
	1-1/4	5/8	5/8	-		5	1-3/8	3	5/8		1-1/2	5/8	7/8	-		8	2-1/2	3	2-1/2	-	
	1-1/2	5/8	7/8	-		1-3/4	3/4	1	-		2-1/4	1	1-1/4	-		10	2-1/2	3	4-1/2	-	
	1-3/4	3/4	1	-		2	1	1	-		2-1/2	1	1-1/2	-		12	2-1/2	3	6-1/2	-	
	2	1	1	-		3	1-1/2	1-1/2	-		2-3/4	1-1/4	1-1/2	-		14	2-1/2	3	8-1/2	-	
10-24	1	3/8	5/8	-	5/16-18	3-1/2	1-1/2	2	-		1/2-13	3	1	2		-	3	1	2	-	
	1-1/4	5/8	5/8	-		3	1-1/2	1-1/2	-			3-1/2	1-1/2	2		-	4	2	2	-	
	1-1/2	5/8	7/8	-		3-3/4	1-3/4	2	-	4		2	2	-	5	2	3	-			
	1-3/4	3/4	1	-		4	2	2	-	4-1/2		1-1/8	3	3/8	6	2-1/2	3	1/2	-		
	2	1	1	-		4-1/2	1-1/8	3	3/8	5		1-3/8	3	5/8	8	2-1/2	3	2-1/2	-		
	2-1/2	1	1-1/2	-		5	1-3/8	3	5/8	10		2-1/2	3	4-1/2	12	2-1/2	3	6-1/2	-		
	3	1-1/2	1-1/2	-		5-1/2	1-1/2	3	1	12		2-1/2	3	6-1/2							
	3-1/2	1-1/2	2	-		6	1-1/2	3	1-1/2												
1/4-20	1	3/8	5/8	-																	
	1-1/4	5/8	5/8	-																	
	1-1/2	5/8	7/8	-																	
	1-3/4	3/4	1	-																	

Tolerance on Length		Up to 6": ± 1/16"	Over 6": ± 1/8"
Description	Bolt with threaded areas at both ends-lag screw thread at one end and unified thread at the other. Standard hanger bolts are designed for insertion into a predrilled pilot hole. The end of the wood thread is designed as a taper which is threaded all the way to its blunt tip.		
Applications / Advantages	Designed to hang material from wooden structures. The lag is wrenched into the wood and the assembly is completed after applying a nut. Used for suspending electrical wiring and sheet metal. Also common in the furniture industry.		
Material	Steel: AISI 1008 & 1010 steel Stainless: Type 303 or 304 stainless steel		
Core Hardness (Steel only)	<i>No. 10 through 1/2 in. diameter, all lengths:</i> Rockwell B80 - B100		
Tensile Strength (Steel only)	<i>No. 10 through 1/2 in. diameter, all lengths:</i> 74,000 psi. minimum (applies only to stresses applied to the Unified thread-side of the fastening)		
Plating	See Appendix-A for plating information.		